

NIDDY NODDY and NIDDY NODDY SAMPLER

Wind yarn into a 1.5m (60") skein on the standard size Niddy Noddy or a 90cm (36") skein on the Niddy Noddy Sampler for washing and dyeing.

Finishing

We recommend the Niddy Noddy be first sanded smooth using a fine grit sandpaper. Then seal the wood to protect it from climatic changes and staining, this will also enhance its character and beauty. Our natural Ashford Wax Finish is ideal for this purpose.





Assembly

To assemble, locate the end pieces onto the ends of the shaft at right angles to each other. To permanently attached one or both end pieces apply a drop of wood glue to the end of the shaft and the hole. Then assemble.

Skein the Wool


Wind the wool directly from the bobbin still on the spinning wheel but leave the brake tension lightly in place to prevent the bobbin over-spinning. Before removing the skein, loosely tie in two or three places to hold it in place. The skein will now fit our standard skein holder for winding into balls.

For more information on fibre preparation, spinning and skeining please refer to "The Ashford Book of Hand Spinning" by Jo Reeve.




e-Spinner


Spinning Wheels from Ashford




Elizabeth 2




Joy 2




Traditional



Traveller



Kiwi 2



Country 2