

ashford INSTRUCTIONS


CLASSIC DROP SPINDLE








Spin the spindle clockwise & allow the leader to join onto your prepared fibres.



While keeping the leader pinched with one hand, draft the fibres down.



Slowly slide your fingers back up the drafted fibres allowing the twist to follow. Once twisted, the yarn will support the weight of the spindle.



Keep the spindle spinning while drafting more yarn until the spindle reaches the floor.



Wind the yarn around the shaft to form a cone & then repeat the process.

Slide the cone off the shaft & use either as a single or ply 2 together with the spindle spinning anti-

clockwise.

Ashford Handicrafts Ltd.
Factory and Showroom: 415 West Street,
PO Box 474, Ashburton, New Zealand
Telephone 64 3 308 9087
Facsimile 64 3 308 8664
Email: sales@ashford.co.nz
Internet: www.ashford.co.nz